ENERGY STAR® Labeled Furnaces
Qualifying Product List
As of September 20, 2002

Manufacturer Name (Trade Name)	Product Family Name	AFUE Rating	Model Series
Adams Manufacturing	Condensing Oil Furnace	95	AHEO Series Oil Furnaces
Adams Manufacturing	Condensing Oil Furnace	95	ASHEO Series Oil Furnaces
Air-Ease	Ultra SX 90	90	All models beginning with GUK or GCK
Air-Ease	Ultra SX 93	93	All models beginning with GU 93
Air-Ease	Ultra SX 95	95	All models beginning with GU 95
Air-Ease	Ultra V Tech 90	90	All models beginning with G1D90
Air-Ease	Ultra V Tech 91	91	All models beginning with G1D91
Air-Ease	Ultra V Advantage 93	93	All models beginning with G1D93
Air-Ease	Ultra V Enhanced 95	94 - 94.5	All models beginning with G1D95
AirQuest	DV 90	90	All models beginning with NTGS
AirQuest	DV 90	91	All models beginning with NUG9
AirQuest	DC 90 (upflow/horiz)	92	All models beginning with NTGM
AirQuest	94V	94	All models beginning with NTVM
AirQuest	NTPM	92	All models beginning with NTPM
AirQuest	NCPM	92	All models beginning with NCPM
AirQuest	DC 90 (downflow/horiz)	92	All models beginning with NCGM
AirQuest	NTGS	91	All models beginning with NTGS
AirQuest	PS 90 Series	90	All models beginning with N9MP1
AirQuest	PS 90-DV Series	90	All models beginning with N9MP2
AirQuest	DLX 90 Series	92	All models beginning with H9MPD
AirQuest	IIS 90 Series	92	All models beginning with H9MPT
Arcoaire	VS 90 Series	92	All models beginning with H9MPV
Arcoaire	GNM	91	All models beginning with GNM
Arcoaire	94V	94	All models beginning with VNK
Arcoaire	TNK 92	92	All models beginning with TNK
Arcoaire	TCK 90	92	All models beginning with TCK
Arcoaire	GNK (upflow/horiz)	92	All models beginning with GNK
Arcoaire	GCK (downflow/horiz)	90	All models beginning with GCK
Arcoaire	GNP	91	All models beginning with GNP
Arcoaire	DC90 (upflow/horiz)	92	All models beginning with NTGM
Arcoaire	DC90 (downflow/horiz)	90	All models beginning with NCGM
Arcoaire	NTGS	91	All models beginning with NTGS
Arcoaire	DV90	91	All models beginning with NTG9
Arcoaire	(None)	90	All models beginning with GUM
Arcoaire	Enviroplus 90	90.1-92	All models beginning with GUK, GDK, GCK
Arcoaire	PS 90 Series	90	All models beginning with N9MP1
Arcoaire	PS 90-DV Series	90	All models beginning with N9MP2
Arcoaire	DLX 90 Series	92	All models beginning with H9MPD
Arcoaire	IIS 90 Series	92	All models beginning with H9MPT
Arcoaire	VS 90 Series	92	All models beginning with H9MPV
Amana	Air Command 90 II	92	All models beginning with GUSA
Amana	Air Command 90	92	All models beginning with GUCA and GCCA
Amana	Air Command 95 II Q	95-96	All models beginning with GUVA and GCVA
American Standard	Freedom 90	91-93	Models with AUY ,ADY, AUC, ADC, AUX ,ADX
Armstrong Air	Ultra SX 90	90	All models beginning with GUK or GCK
Armstrong Air	Ultra SX 93	93	All models beginning with GU 93
Armstrong Air	Ultra SX 95	95	All models beginning with GU 95
Armstrong Air	Ultra V Tech 90	90	All models beginning with G1D90
Armstrong Air	Ultra V Tech 91	91	All models beginning with G1D91
Armstrong Air	Ultra V Advantage 93	93	All models beginning with G1D93
Armstrong Air	Ultra V Enhanced 95	94 - 94.5	All models beginning with G1D95
Carrier Corporation (Bryant)	Condensing Furnace	91	All models beginning with 340MAV
Carrier Corporation (Bryant)	Condensing Furnace	90	All models beginning with 345MAV
Carrier Corporation (Bryant)	Condensing Furnace	90	All models beginning with 351DAS
Carrier Corporation (Bryant)	Plus 90	92	All models beginning with 350MAV
Carrier Corporation (Bryant)	Plus 90i	94-96	All models beginning with 355MAV

ENERGY STAR® Labeled Furnaces
Qualifying Product List
As of September 20, 2002

Manufacturer Name (Trade Name)	Product Family Name	AFUE Rating	Model Series
Carrier Corporation (Bryant)	Plus 90t	93	All models beginning with 352MAV
Carrier Corporation (Bryant, Day&Night, Payne)	Condensing Furnace	91	All models beginning with 340MAV
Carrier Corporation (Bryant, Day&Night, Payne)	Condensing Furnace	90	All models beginning with 345MAV
Carrier Corporation (Bryant, Day&Night, Payne)	Plus 90	92	All models beginning with 350MAV
Carrier Corporation (Bryant, Day&Night, Payne)	Plus 90i	94-96	All models beginning with 355MAV
Carrier Corporation (Carrier)	Condensing Furnace	91	All models beginning with 58MCA
Carrier Corporation (Carrier)	Condensing Furnace	91	All models beginning with 58MCA
Carrier Corporation (Carrier)	Condensing Furnace	90	All models beginning with 58MSA
Carrier Corporation (Carrier)	Condensing Furnace	90	All models beginning with 58MSA
Carrier Corporation (Carrier)	Infinity	94-96.6	All models beginning with 58MVP
Carrier Corporation (Carrier)	Infinity	94-96.6	All models beginning with 58MVP
Carrier Corporation (Carrier)	WeatherMaker	92	All models beginning with 58MXA
Carrier Corporation (Carrier)	Weathermaker	92	All models beginning with 58MXA
Carrier Corporation (Carrier)	WeatherMaker 9300TS	93	All models beginning with 58MTA
Carrier Corporation (Payne)	Condensing Furnace	92	All models beginning with 490AAV
Carrier Corporation (Payne)	Condensing Furnace	92	All models beginning with PG9
Consolidated Industries	True Blue 90	90	All models beginning with USA, DSA or DCA
Coleman	Condensing Furnace	92+	G9D
Coleman	Condensing Furnace	92 - 94	G9V
Coleman	Condensing Furnace	94	G9D
Coleman	Condensing Furnace	91 - 94	G9T
Coleman (Custom)	Condensing Furnace	91 - 94	FG9
Coleman-Evcon	90% Down flow	90	DGAD060CD
Coleman-Evcon	90% Down flow	90	DGAE080CD
Coleman-Evcon	90% Down flow	90	DGAF100CD
Coleman-Evcon	Condensing furnace	91 - 94	Models beginning with G9
Comfortmaker	(None)	90	All models beginning with GUM
Comfortmaker	Enviroplus 90	90.1-92	All models beginning with GUK, GDK, GCK
Comfortmaker	NTGS	91	All models beginning with NTGS
Comfortmaker	94V	94	All models beginning with VNK
Comfortmaker	TNK 92	92	All models beginning with TNK
Comfortmaker	TCK 90	92	All models beginning with TCK
Comfortmaker	GNK (upflow/horiz)	92	All models beginning with GNK
Comfortmaker	GCK (downflow/horiz)	90	All models beginning with GCK
Comfortmaker	GNP	91	All models beginning with GNP
Comfortmaker	PS 90 Series	90	All models beginning with N9MP1
Comfortmaker	PS 90-DV Series	90	All models beginning with N9MP2
Comfortmaker	DLX 90 Series	92	All models beginning with C9MPD
Comfortmaker	IIS 90 Series	92	All models beginning with C9MPT
Comfortmaker	VS 90 Series	92	All models beginning with C9MPV
Concord	Concord 90	90	All models beginning with CG90
DMO Industries	Ultramax	90.7-92.7	All models beginning with HDF
Dornback Furnace Division	HEO Series, Oil Fired	95	All models beginning with HEO
Dornback Furnace Division	SHEO Series, Oil Fired	95	All models beginning with SHEO
Ducane Company	Fits All 95	94-95	All models beginning with CMPA
Ducane Company	Fits All 95	92	All models beginning with CMPB
Ducane Company	Classic 94	93-94	All models beginning with FPAA
EVCON		92-94	All models beginning with DGU or DGD
Excel Comfort Systems (Aire-Flo)	Aire-Flo	92	AF90MPA050U3 AF90MPA050C3 AF90MPA075U3 AF90MPA075C3
Excel Comfort Systems (Aire-Flo	Aire-Flo	90	AF90MPA100U4 AF90MPA100C4 AF90MPA125U4 AF90MPA125C4

ENERGY STAR® Labeled Furnaces
Qualifying Product List
As of September 20, 2002

Manufacturer Name (Trade Name)	Product Family Name	AFUE Rating	Model Series
Fraser-Johnston		92-94	All models beginning with P*HD, P*LU or P*ND
Goodman Manufacturing	92 % Condensing	92	All models beginning with GMPN
Goodman Manufacturing	92 % Sealed Combustion	92	All models beginning with GSU
Goodman Manufacturing	92.6%	93	All models beginning with GMNT
Goodman Manufacturing	92 % Combustion	92	All models beginning with GSMS
Goodman Manufacturing	92 % Combustion	92	All models beginning with GSM
Heat Controller (Comfort-Aire) (Century)	Conquest 90	94	FLUA45-E3
Heat Controller (Comfort-Aire) (Century)	Conquest 90	93.3	GLUA60-E3
Heat Controller (Comfort-Aire) (Century)	Conquest 90	92.8	GLUA75-E3
Heat Controller (Comfort-Aire) (Century)	Conquest 90	92.8	GLUA75-E4
Heat Controller (Comfort-Aire) (Century)	Conquest 90	93.5	GLUA90-E5
Heat Controller (Comfort-Aire) (Century)	Conquest 90	92	GLUA105-E5
Heat Controller (Comfort-Aire) (Century)	Conquest 90	94.2	FLUA120-E5
Heat Controller (Comfort-Aire) (Century)	Conquest 90	92.7	ELDH45-E3
Heil	DV90	91	All models beginning with NTG9
Heil	DV90	90	All models beginning with NUG9
Heil	DC90	90.1-92	All models beginning with NUGM, NDGM, NCGM
Heil	94V	94	All models beginning with NTVM
Heil	QuietComfort™ II (upflow/downflow	92	All models beginning with NTPM
Heil	QuietComfort™ II (downflow/horiz)	92	All models beginning with NCPM
Heil	DC90 (upflow/horiz)	92	All models beginning with NTGM
Heil	DC90 (downflow/horiz)	90	All models beginning with NCGM
Heil	PS 90-DV Series	90	All models beginning with N9MP2
Heil	DLX 90 Series	92	All models beginning with H9MPD
Heil	IIS 90 Series	92	All models beginning with H9MPT
Heil	VS 90 Series	92	All models beginning with H9MPV
Lennox Industries	Elite 90 Gas Furnace	90.9-92.4	All models beginning with G26 or GHR26
Lennox Industries	Complete Heat	90	All models beginning with AM30/HM30
Lennox Industries	Dimension Gas Furnace	93.0-94.2	All models beginning with G32
Lennox Industries	Pulse 21 Gas Furnace	93.2-96.2	All models beginning with G21 or GSR21
Lennox Industries	Pulse 21V Gas Furnace	93.4-94.5	All models beginning with G21V or GSR21V
Lennox Industries	Dimension Gas Furnace	90	All models beginning with GHR32
Luxaire	High Performance	92	P*LU or P*LD
Luxaire	Peak Performance	92 - 94	G9V
Luxaire	High Performance	91 - 94	G9T
Luxaire	Performance Plus	91 - 94	G9D
Luxaire (Basis)	Condensing furnace	91 - 94	FG9
Kenmore	PS 90 Series	90	All models beginning with N9MP1
Kenmore	PS 90-DV Series	90	All models beginning with N9MP2
Kenmore	DLX 90 Series	92	All models beginning with C9MPD
Kenmore	DLX 90 Series	92	All models beginning with T9MPD
Kenmore	IIS 90 Series	92	All models beginning with C9MPT
Kenmore	IIS 90 Series	92	All models beginning with H9MPT
Kenmore	IIS 90 Series	92	All models beginning with T9MPT
Kenmore	VS 90 Series	92	All models beginning with C9MPV
Kenmore	VS 90 Series	92	All models beginning with H9MPV
Kenmore	VS 90 Series	92	All models beginning with T9MPV
NORDYNE Inc. (Gibson)	Condensing Furnace	92	All KG6RC models
NORDYNE Inc. (Gibson)	Condensing Furnace	92	All KG6RL models
NORDYNE Inc. (Grandaire)	Condensing Furnace	92	All KG6RC models
NORDYNE Inc. (Grandaire)	Condensing Furnace	92	All KG6RL models
NORDYNE Inc. (Intertherm)	Condensing Furnace	92	All G6RC models
NORDYNE Inc. (Intertherm)	Condensing Furnace	92	All G6RL models
NORDYNE Inc. (Intertherm)	Condensing Furnace	92	All G6T models
NORDYNE Inc. (Intertherm)	Condensing Furnace	92	All M2R models
NORDYNE Inc. (Frigidaire)	Condensing Furnace	92	All FG6RC models

ENERGY STAR® Labeled Furnaces
Qualifying Product List
As of September 20, 2002

Manufacturer Name (Trade Name)	Product Family Name	AFUE Rating	Model Series
NORDYNE Inc. (Frigidaire)	Condensing Furnace	92	All FG6RL models
NORDYNE Inc. (Frigidaire)	Condensing Furnace	92	All FG6T models
NORDYNE Inc. (Kelvinator)	Condensing Furnace	92	All G6RC models
NORDYNE Inc. (Kelvinator)	Condensing Furnace	92	All G6RL models
NORDYNE Inc. (Kelvinator)	Condensing Furnace	92	All G6T models
NORDYNE Inc. (Maytag)	Condensing Furnace	92	All PGF1RC models
NORDYNE Inc. (Maytag)	Condensing Furnace	90	All PGF1RL models
NORDYNE Inc. (Maytag)	Condensing Furnace	92	All PGF1T* models
NORDYNE Inc. (Miller)	Condensing Furnace	92	All G6RC models
NORDYNE Inc. (Miller)	Condensing Furnace	92	All G6RL models
NORDYNE Inc. (Miller)	Condensing Furnace	92	All M2R models
NORDYNE Inc. (Philco)	Condensing Furnace	92	All G6RC models
NORDYNE Inc. (Philco)	Condensing Furnace	92	All G6RL models
NORDYNE Inc. (Philco)	Condensing Furnace	92	All G6T models
NORDYNE Inc. (Tappan)	Condensing Furnace	92	All FG6RC models
NORDYNE Inc. (Tappan)	Condensing Furnace	92	All FG6RL models
NORDYNE Inc. (Tappan)	Condensing Furnace	92	All FG6T models
NORDYNE Inc. (Thermal Zone)	Condensing Furnace	92	All G6RC models
NORDYNE Inc. (Thermal Zone)	Condensing Furnace	90	All G6RL models
NORDYNE Inc. (Thermal Zone)	Condensing Furnace	92	All G6T* models
NORDYNE Inc. (Westinghouse)	Condensing Furnace	92	All FG6RC models
NORDYNE Inc. (Westinghouse)	Condensing Furnace	90	All FG6RL models
NORDYNE Inc. (Westinghouse)	Condensing Furnace	92	All FG6T* models
Oneida Royal	Royal Air 90 U Series	90	90U050D30AZC, 90U050D36AZC, 90U075D30AZC, 90U075D42AZC, 90U100D42AZC, 90U125D60AZC
Payne	Condensing Furnaces	90-92	PG9M
Rheem Manufacturing (Rheem)	FURN/Classic 90 Plus	92-94	All models beginning with RGRA, RGTA
Rheem Manufacturing (Rheem)	FURN/Classic 90	92	All models beginning with RGRJ, RGTJ
Rheem Manufacturing (Rheem)	FURN/Classic 90 Plus w/CCC	94	All models beginning with RGFD, RGGD
Rheem Manufacturing (Ruud)	FURN/Achiever 90 Plus	92-94	All models beginning with UGRA, UGTA
Rheem Manufacturing (Ruud)	FURN/Achiever 90	92	All models beginning with UGRJ, UGTJ
Rheem Manufacturing (Ruud)	FURN/Achiever 90 Plus w/CCC	94	All models beginning with UGFD, UGGD
Rheem Manufacturing (WeatherKing)	FURN/Select 90 Plus	92-94	All models beginning with WGRA, WGTA
Rheem Manufacturing (WeatherKing)	FURN/Select 90	92	All models beginning with WGRJ, WGTJ
Rheem Manufacturing (WeatherKing)	FURN/Select 90 Plus w/CCC	94	All models beginning with WGFD, WGGD
Rheem Manufacturing (WeatherKing LLC)	FURN / 90	90%	All models beginning with 90RJ, 90TJ
Rheem Manufacturing (Corsaire)	FURN/ 90	90	All models beginning with FGRJ, FGTJ
Rheem Manufacturing (Zephyr)	FURN/ 90	90	All models beginning with EGRJ, EGTJ
Tempstar	DV 90	90	All models beginning with NTG9
Tempstar	DV 90	90	All models beginning with NUG9
Tempstar	DC 90	90.1-92	All models beginning with NUGM, NDGM, NCGM
Tempstar	94V	94	All models beginning with NTVM
Tempstar	SmartComfort™ II (upflow/downflow)	92	All models beginning with NTPM
Tempstar	SmartComfort™ II (downflow/horiz)	92	All models beginning with NCPM
Tempstar	DC90 (upflow/horiz)	92	All models beginning with NTGM
Tempstar	DC90 (downflow/horiz)	90	All models beginning with NCGM
Tempstar	NTGS	91	All models beginning with NTGS
Tempstar	PS 90 Series	90	All models beginning with N9MP1
Tempstar	PS 90-DV Series	90	All models beginning with N9MP2
Tempstar	DLX 90 Series	92	All models beginning with T9MPD
Tempstar	IIS 90 Series	92	All models beginning with T9MPT
Tempstar	VS 90 Series	92	All models beginning with T9MPV
Texas Furnace, LLC	TFC + 90	90.4	CSA Series
Texas Furnace, LLC	Meridian + 90	90.4	CSA Series
Texas Furnace, LLC	TFC + 90	90.9	VSA Series
Texas Furnace, LLC	Meridian + 90	90.9	VSA Series

ENERGY STAR® Labeled Furnaces
Qualifying Product List
As of September 20, 2002

Manufacturer Name (Trade Name)	Product Family Name	AFUE Rating	Model Series
Thermal Zone	90% Multi Position Furnace	90	All models beginning GU***M
Thermal Zone	90% Downflow Furnace	90	All models beginning with GD***M
Thermal Zone	93% Upflow Furnace	93	All models beginning with GU***N
ThermoPride	CCA	90-96	All models beginning with CCA
ThermoPride	CHB	93-95	All models beginning with CHB
ThermoPride	CCB	92-95	All models beginning with CCB
Trane	XB90	92	All models beginning with TUC
Trane	XB90	91	All models beginning with TDC
Trane	XR 90	92	All models beginning with TUX
Trane	XR 90	91	All models beginning with TDX
Trane	XL90	92.5-93	All models beginning with TUX-R
Trane	XL90	92.5-93	All models beginning with TDX-R
Trane	XV 90	92.5-93	All models beginning with TUY
Trane	XV 90	92.1-93	All models beginning with TDY
Thermo Products Incorporated (Thermo Pride)	CHA	92-93	All models beginning with CHA
Thermo Products Incorporated (Thermo Pride)	CHA/CCA	90-96	All models beginning with GLC
York International Corporation (Choice)	Condensing furnace	91 - 94	FG9
York International Corporation	Deluxe Diamond 95 Series	94-95	P*XU
York International Corporation	Diamond 90 Series	90	P*DR
York International Corporation	Diamond 90 Series	91 - 94	P*UR, P*DH
York International Corporation	Diamond 95 Ultra Series	92 - 94	P*XU-V, PXD-V

Note: Armstong produces Air-Ease (a Johnson line) and Concord.

Note: York International produces Coleman, Coleman Evcon, Evcon, Luxaire, and Fraser-Johnston products

Note: ICP produces Airquest, Arcoaire, Comfortmaker, Heil, and Tempstar products