Section D Page 1 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

# Facility Equipment and Requirements (Section D)

This section consists of a table listing all permitted equipment at the facility, facility wide requirements, all individual Permits to Construct and Permits to Operate issued to various equipment at the facility, and Rule 219-exempt equipment subject to source-specific requirements. Each permit and Rule 219-exempt equipment will list operating conditions including periodic monitoring requirements, and applicable emission limits and requirements that the equipment is subject to. Also included is the rule origin and authority of each emission limit and permit condition.

Section D Page 2 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

## PERMITTED EQUIPMENT LIST

THE FOLLOWING IS A LIST OF ALL PERMITS TO CONSTRUCT AND PERMITS TO OPERATE AT THIS FACILITY:

<b>Application number</b>	Permit to Operate number	<b>Equipment description</b>
317616	F4131	I C E (>500 HP) EM ELEC GEN DIESEL
358501	F22021	I C E (>-500 HP) EM ELEC GEN-DIESEL
419503	F71623	AFTERBURNER, VENT S.S. <1 MMBTU/HR
443789	F83293	I C E (>-500 HP) EM ELEC GEN-DIESEL
447835	F83295	ETHYLENE OXIDE STERILIZER, HOSPITAL
447836	F83294	ETHYLENE OXIDE STERILIZER, HOSPITAL
447837	F83299	AFTERBURNER, CATALYTIC ≤1 MMBTU/HR
487407	G21362	BOILER (5-20 MMBTU/HR) NAT GAS ONLY
487409	G21363	BOILER (5-20 MMBTU/HR) NAT GAS ONLY
487410	G21364	BOILER (5-20 MMBTU/HR) NAT GAS ONLY
487445	F99218	BOILER (<5 MMBTU/HR) NAT GAS ONLY
487446	F99219	BOILER (<5 MMBTU/HR) NAT GAS ONLY
487447	F99220	BOILER (<5 MMBTU/HR) NAT GAS ONLY
487448	F99221	BOILER (<5 MMBTU/HR) NAT GAS ONLY
497147	G5761	SCRUBBER, CONTROLLING HCL OR NH3
518884	G13002	SCRUBBER, TOXICS
518885	G13004	SCRUBBER, TOXICS
518886	G13003	SCRUBBER, TOXICS
524958	G15506	EXTRUDER
526846	G15507	EXTRUDER
529249	G16455	LASER CUTTING MACHINE
560736	GXXXX	SPRAY BOOTH
572699	GXXXX	STERILIZATION SYSTEM NOX, OTHER

**NOTE:** EQUIPMENT LISTED ABOVE THAT HAS NO CORRESPONDING PERMIT TO OPERATE NUMBER IS ISSUED PERMIT TO CONSTRUCT. THE ISSUANCE OR DENIAL OF ITS PERMIT TO OPERATE IS SUBJECT TO ENGINEERING FINAL REVIEW. ANY OTHER APPLICATIONS THAT ARE STILL BEING PROCESSED AND HAVE NOT BEEN ISSUED PERMITS TO CONSTRUCT OR PERMITS TO OPERATE WILL NOT BE FOUND IN THIS TITLE V PERMIT.

Section D Page 3 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### **FACILITY WIDE CONDITION(S)**

- 1. EXCEPT FOR OPEN ABRASIVE BLASTING OPERATIONS, THE OPERATOR SHALL NOT DISCHARGE INTO THE ATMOSPHERE FROM ANY SINGLE SOURCE OF EMISSIONS WHATSOEVER ANY AIR CONTAMINANT FOR A PERIOD OR PERIODS AGGREGATING MORE THAN THREE MINUTES IN ANY ONE HOUR WHICH IS:
  - A. AS DARK OR DARKER IN SHADE AS THAT DESIGNATED NO. 1 ON THE RINGLEMANN CHART, AS PUBLISHED BY THE UNITED STATES BUREAU OF MINES; OR
  - B. OF SUCH OPACITY AS TO OBSCURE AN OBSERVER'S VIEW TO A DEGREE EQUAL TO OR GREATER THAN DOES SMOKE DESCRIBED IN SUBPARAGRAPH (A) OF THIS CONDITION. [RULE 401]
- 2. THE OPERATOR SHALL NOT USE FUEL OIL CONTAINING SULFUR COMPOUNDS IN EXCESS OF 15 PPM BY WEIGHT.
  [RULE 431.2]
- 3. THE OPERATOR SHALL NOT USE GASEOUS FUEL CONTAINING SULFUR COMPOUNDS IN EXCESS OF 40 PPMV CALCULATED AS HYDROGEN SULFIDE AVERAGED OVER FOUR HOURS. [RULE 431.1].

Section D Page 4
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F4131 A/N 317616

### **Equipment Description:**

INTERNAL COMBUSTION ENGINE, CATERPILLAR, MODEL 3512 TA, TWELVE CYLINDER, DIESEL FUELED, 1568 B.H.P., TURBOCHARGED/AFTERCOOLED, DRIVING AN EMERGENCY ELECTRICAL GENERATOR.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.

  [RULE 204]
- 3. THE OPERATING TIME OF THIS ENGINE SHALL NOT EXCEED 199 HOURS IN ANY ONE YEAR. [RULE 1110.2, 1304(a)(4)-OFFSET AND MODELING EXEMPTION]
- 4. A NON-RESETTABLE TIMER SHALL BE MAINTAINED TO INDICATE THE ENGINES ELAPSED OPERATING TIME.
  [RULE 1110.2, 1304(a)(4)-OFFSET AND MODELING EXEMPTION]
- 5. AN ENGINE OPERATING LOG LISTING THE DATE OF OPERATION, THE ELAPSED OPERATING TIME, IN HOURS, AND THE REASON FOR OPERATION SHALL BE KEPT AND MAINTAINED ON FILE FOR A MINIMUM OF FIVE YEARS AND MADE AVAILABLE TO AQMD PERSONNEL UPON REQUEST.

  [RULE 1110.2, 1304(a)(4)-OFFSET AND MODELING EXEMPTION]
- 6. THIS ENGINE SHALL HAVE THE FUEL INJECTION TIMING RETARDED BY FOUR DEGREES WITH RESPECT TO STANDARD TIMING.
  [RULE 1303(a)(1)-BACT]

### **Emissions And Requirements:**

7. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

PM: RULE 404, SEE APPENDIX B FOR EMISSION LIMITS [Rule 404]

Section D Page 5 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F22021 A/N 358501

### **Equipment Description:**

INTERNAL COMBUSTION ENGINE, CATERPILLAR, 16 CYLINDERS, TURBOCHARGED, AFTERCOOLED, MODEL NO. 3516 DITA (1750 KW), 2518 BHP, DIESEL-FUELED, DRIVING AN EMERGENCY ELECTRICAL GENERATOR.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. A TIMER SHALL BE MAINTAINED TO INDICATE THE ENGINE ELAPSED OPERATING TIME. [RULE 1303(a)(1)-BACT]
- 4. THE OPERATING TIME OF THIS ENGINE SHALL NOT EXCEED 72 HOURS IN ANY ONE YEAR. [RULE 1303(a)(1)-BACT]
- 5. AN ENGINE OPERATING LOG LISTING THE DATE OF OPERATION, THE ELAPSED TIME, IN HOURS, AND THE REASON FOR OPERATION SHALL BE KEPT AND MAINTAINED ON FILE FOR A MINIMUM OF TWO YEARS AND MADE AVAILABLE TO DISTRICT PERSONNEL UPON REQUEST. [RULE 1303(a)(1)-BACT]
- 6. THE FUEL INJECTION TIMING OF THIS ENGINE SHALL BE SET AND MAINTAINED AT 4
  DEGREES RETARDED RELATIVE TO PRODUCTION TIMING AS ESTABLISHED BY CATERPILLAR
  IN PRODUCT NEWS BULLETIN 'REQUIREMENTS TO COMPLY WITH SCAQMD CERTIFIED
  EQUIPMENT.
  [RULE 1303(a)(1)-BACT]

### **Emissions And Requirements:**

7. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

PM: RULE 404. SEE APPENDIX B FOR EMISSION LIMITS [RULE 404]

Section D Page 6 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F71623 A/N 419503

### **Equipment Description:**

AIR POLLUTION CONTROL SYSTEM CONSISTING OF:

- 1. CATALYTIC OXIDIZER, DONALDSON, MODEL ETO ABATOR, WITH 8.5 KW ELECTRICAL PREHEATER .
- 2. EXHAUST SYSTEM WITH A 3/4-H.P. BLOWER VENTING TO TWO STERILIZERS.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. CATALYST BED TEMPERATURE SHALL BE MAINTAINED ABOVE 280 DEGREES F AND NOT TO EXCEED 500 DEGREES F EXCEPT DURING START-UP OPERATIONS.

  [RULE 1303(a)(1)-BACT]
- THIS EQUIPMENT SHALL NOT BE PURGED OR AIRWASHED UNLESS IT IS VENTED TO THE AIR POLLUTION CONTROL EQUIPMENT, WHICH IS IN FULL USE AND HAS BEEN ISSUED A PERMIT TO OPERATE.

  [RULE 1303(a)(1)-BACT]
- 5. THIS EQUIPMENT SHALL BE IN FULL USE WHEN THE STERILIZER IT SERVES IS IN OPERATION. [RULE 1303(a)(1)-BACT
- 6. THE STERILIZER EXHAUST SYSTEM SHALL BE LEAK FREE. [RULE 1303(a)(1)-BACT]
- 7. LEAK INSPECTIONS SHALL BE CONDUCTED ONCE EVERY SIX MONTHS IN ACCORDANCE WITH RULE 1405.

  [RULE 1405]
- 8. RECORDS OF THE LEAK INSPECTIONS SHALL BE MAINTAINED IN ACCORDANCE WITH RULE 1405, AND KEPT ON FILE FOR AT LEAST FIVE YEARS AND BE MADE AVAILABLE TO DISTRICT STAFF UPON REQUEST.
  [Rue 1405]
- 9. THIS EQUIPMENT SHALL COMPLY WITH THE REQUIREMENTS OF RULE 1405. [Rule 1405]

Section D Page 7 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F83293 A/N 443789

### **Equipment Description:**

INTERNAL COMBUSTION ENGINE, CATERPILLAR, 6 CYLINDER, TURBOCHARGED, AFTERCOOLED, MODEL 3456 DITA AA. 764 BHP. DIESEL FUELED, DRIVING AN EMERGENCY ELECTRICAL GENERATOR.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THE OPERATION OF THIS ENGINE BEYOND 20 HOURS PER YEAR FOR MAINTENANCE AND PERFORMANCE TESTING SHALL BE ALLOWED ONLY IN THE EVENT OF A LOSS OF GRID POWER OR UP TO 30 MINUTES PRIOR TO ROTATING OUTAGES, PROVIDED THAT THE UTILITY DISTRIBUTION COMPANY HAS ORDERED ROTATING OUTAGES IN THE CONTROL AREA WHERE THE ENGINE IS LOCATED, OR HAS INDICATED THAT THE DISTRIBUTION COMPANY IS EXPECTED TO ISSUE SUCH ORDER AT A CERTAIN TIME, AND THE ENGINE IS LOCATED IN THE UTILITY SERVICE BLOCK THAT IS SUBJECT TO THE ROTATING OUTAGE. ENGINE OPERATION SHALL BE TERMINATED IMMEDIATELY AFTER THE UTILITY DISTRIBUTION COMPANY ADVISES THAT A ROTATING OUTAGE IS NO LONGER IMMINENT OR IN EFFECT. [RULE 1470]
- 4. THIS ENGINE SHALL NOT BE OPERATED MORE THAN A TOTAL OF 200 HOURS IN ANY ONE CALENDAR YEAR, WHICH INCLUDES NO MORE THAN 20 HOURS FOR MAINTENANCE AND PERFORMANCE TESTING.
  [RULE 1470]
- 5. AN OPERATIONAL, NON-RESETTABLE ELAPSED TIME METER SHALL BE INSTALLED AND MAINTAINED TO INDICATE THE ENGINE ELAPSED OPERATING TIME. [RULE 1470]
- 6. THIS ENGINE SHALL NOT BE USED AS PART OF A DEMAND RESPONSE PROGRAM USING INTERRUPTIBLE SERVICE CONTRACT IN WHICH A FACILITY RECEIVES A PAYMENT OR REDUCED RATE IN RETURN FOR REDUCING ITS ELECTRIC LOAD ON THE GRID WHEN REQUESTED TO DO SO BY THE UTILITY COMPANY OR THE GRID OPERATOR. [RULE 1470]

Section D Page 8
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

7. THIS ENGINE SHALL COMPLY WITH ALL APPLICABLE REQUIREMENTS OF RULES 431.2 AND 1470.

[RULES 431.2, 1470]

### **Periodic Monitoring**

- 8. AN ENGINE OPERATING LOG SHALL BE MAINTAINED ON A MONTHLY BASIS, WHICH SHALL INCLUDE MANUAL AND AUTOMATIC OPERATION AND SHALL LIST ALL ENGINE OPERATIONS IN EACH OF THE FOLLOWING AREAS:
  - A. EMERGENCY USE HOURS OF OPERATION
  - B. MAINTENANCE AND TESTING HOURS
  - C. OTHER OPERATING HOURS (DESCRIBE THE REASON FOR OPERATION). IN ADDITION, EACH TIME THE ENGINE IS STARTED MANUALLY, THE LOG SHALL INCLUDE THE DATE OF OPERATION AND THE TIMER READING IN HOURS AT THE BEGINNING AND END OF OPERATION. THE LOG SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND BE MADE AVAILABLE TO DISTRICT STAFF UPON REQUEST. THE TOTAL HOURS OF OPERATION FOR THE PREVIOUS CALENDAR YEAR SHALL BE RECORDED SOMETIME DURING THE FIRST 15 DAYS OF JANUARY OF EACH YEAR.

[RULE 3004(a)(4)- MONITORING AND RECORDKEEPING]

Section D Page 9 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F83295 A/N 447835

### **Equipment Description:**

STERILIZER, ETHYLENE OXIDE, 3M MODEL 8 XL, 8.8 CUBIC FEET INTERNAL CAPACITY.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.

  [RULE 204]
- 3. THE OPERATOR SHALL NOT OPERATE THIS STERILIZER UNLESS IT IS VENTED TO AN AIR POLLUTION CONTROL EQUIPMENT, WHICH IS IN FULL USE AND HAS BEEN ISSUED A PERMIT TO OPERATE BY THE EXECUTIVE OFFICER.

  [Rule 1303(a)(1)-BACT]
- 4. THIS EQUIPMENT SHALL NOT USE MORE THAN 170 GRAMS OF ETHYLENE OXIDE IN ANY ONE CYCLE.
  [Rule 1401]
- 5. THE OPERATOR SHALL CONDUCT NO MORE THAN TWO STERILIZING CYCLES IN THIS EQUIPMENT IN ANY ONE DAY.
  [Rule 1401]
- 6. THE OPERATOR SHALL MAINTAIN THE STERILIZER EXHAUST SYSTEM TO BE LEAK FREE, WITH LEAK TESTS CONDUCTED EVERY SIX MONTHS IN ACCORDANCE WITH THE TEST METHODS SPECIFIED IN RULE 1405.
  [Rule 1405]
- 7. THE OPERATOR SHALL NOT PURGE OR AIRWASH THIS EQUIPMENT UNLESS IT IS VENTED TO AN AIR POLLUTION CONTROL EQUIPMENT, WHICH IS IN FULL USE AND HAS BEEN ISSUED A PERMIT TO OPERATE.

  [Rule 1304(a)(1)]

### **Periodic Monitoring:**

8. THE OPERATOR SHALL MAINTAIN A DAILY OPERATING LOG AND RECORD THE LEAK TESTS IN ACCORDANCE WITH RULE 1405, WHICH SHALL BE KEPT ON FILE FOR AT LEAST FIVE YEARS, AND BE MADE AVAILABLE TO AQMD PERSONNEL UPON REQUEST.
[RULE 3004(a)(4)- MONITORING AND RECORDKEEPING]

Section D Page 10 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F83294 A/N 447836

### **Equipment Description:**

STERILIZER, ETHYLENE OXIDE, 3M, MODEL 8XL, 8.8 CUBIC FEET INTERNAL CAPACITY.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.

  [RULE 204]
- 3. THE OPERATOR SHALL NOT OPERATE THIS STERILIZER UNLESS IT IS VENTED TO AN AIR POLLUTION CONTROL EQUIPMENT, WHICH IS IN FULL USE AND HAS BEEN ISSUED A PERMIT TO OPERATE BY THE EXECUTIVE OFFICER.

  [Rule 1304(a)(1) BACT]
- 4. THIS EQUIPMENT SHALL NOT USE MORE THAN 170 GRAMS OF ETHYLENE OXIDE IN ANY ONE CYCLE.
  [Rule 1401]
- 5. THE OPERATOR SHALL CONDUCT NO MORE THAN TWO STERILIZING CYCLES IN THIS EQUIPMENT IN ANY ONE DAY.
  [Rule 1401]
- 6. THE OPERATOR SHALL MAINTAIN THE STERILIZER EXHAUST SYSTEM TO BE LEAK FREE, WITH LEAK TESTS CONDUCTED EVERY SIX MONTHS IN ACCORDANCE WITH THE TEST METHODS SPECIFIED IN RULE 1405.
  [RULE 1405]
- 7. THE OPERATOR SHALL NOT PURGE OR AIRWASH THIS EQUIPMENT UNLESS IT IS VENTED TO AN AIR POLLUTION CONTROL EQUIPMENT, WHICH IS IN FULL USE AND HAS BEEN ISSUED A PERMIT TO OPERATE.

  [RULE 1304(a)(1) BACT]

### **Periodic Monitoring:**

8. THE OPERATOR SHALL MAINTAIN A DAILY OPERATING LOG AND RECORD THE LEAK TESTS IN ACCORDANCE WITH RULE 1405, WHICH SHALL BE KEPT ON FILE FOR AT LEAST FIVE YEARS, AND BE MADE AVAILABLE TO AQMD PERSONNEL UPON REQUEST.

[RULE 1405, 3004(a)(4)MONITORING AND RECORDKEEPING]

Section D Page 11 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F83299 A/N 447837

### **Equipment Description:**

#### AIR POLLUTION CONTROL SYSTEM CONSISTING OF:

- 1. CATALYTIC OXIDIZER, 3M, MODEL 50 SCFM, 5 KW ELECTRIC PREHEATER.
- 2. EXHAUST BLOWER, 2 HP, 50 CFM

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THE CATALYST BED TEMPERATURE SHALL BE MAINTAINED ABOVE 280 BUT NOT TO EXCEED 500 DEGREES F EXCEPT DURING START-UP OPERATIONS OF THIS EQUIPMENT. [RULE 1303(a)(1)-BACT]
- 4. THE OPERATOR SHALL INSTALL AND MAINTAIN A CONTINUOUS TEMPERATURE INDICATOR AND RECORDER TO ACCURATELY INDICATE AND RECORD THE TEMPERATURE AT THE EXHAUST OF THE OXIDIZER.

  [RULE 1303(a)(1)-BACT]
- 5. THIS EQUIPMENT SHALL BE IN FULL USE WHEN THE STERILIZER IT SERVES IS IN OPERATION. [RULE 1303(a)(1)-BACT]
- 6. ONLY ONE STERILIZER SHALL BE VENTED TO THIS EQUIPMENT AT ANY ONE TIME. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF RULE 1405. [RULE 1303(a)(1)-BACT]
- 7. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF RULE 1405. [RULE 1405]

Section D Page 12 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G21362 A/N 487407

### **Equipment Description:**

BOILER NO. 1, WATERTUBE TYPE, CLEAVER BROOKS MODEL FLX 700-800, EQUIPPED WITH LOW NO  $_{\rm X}$  BURNER, 8 MMBTU/HR, NATURAL GAS FIRED.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THE BOILER SHALL BE EQUIPPED WITH A CONTROL SYSTEM TO AUTOMATICALLY REGULATE COMBUSTION AIR AND FUEL AS THE BOILER LOAD VARIES. THIS AUTOMATIC CONTROL SYSTEM SHALL BE ADJUSTED AND TUNED AT LEAST ONCE EVERY SIX MONTHS ACCORDING TO THE MANUFACTURER'S SPECIFICATIONS TO MAINTAIN ITS ABILITY TO REPEAT THE SAME PERFORMANCE AT THE SAME FIRING RANGE. NOX,  $O_2$ , AND CO SHALL BE MEASURED AND RECORDED ALONG WITH THE TUNE-UP PROCEDURES. [Rule 1146]
- 4. THE  $NO_X$  AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

#### POLLUTANTS PPMV

NO<sub>X</sub> 12 CO 100 [Rule 1303(a)-BACT]

5. THE OPERATOR SHALL NOT OPERATE ALL OF THE THREE BOILERS AT THE SAME TIME. [Rule 1303(b)(2)-OFFSET]

### **Periodic Monitoring:**

6. RECORDS SHALL BE MAINTAINED TO PROVE COMPLIANCE WITH CONDITION NO. 5. SUCH RECORDS SHALL BE KEPT FOR AT LEAST THE LAST FIVE YEARS AND BE MADE AVAILABLE TO DISTRICT PERSONNEL UPON REQUEST.

[RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 13 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G21363 A/N 487409

### **Equipment Description:**

BOILER NO. 2, WATERTUBE TYPE, CLEAVER BROOKS MODEL FLX 700-800, EQUIPPED WITH LOW NO  $_{\rm X}$  BURNER. 8 MMBTU/HR. NATURAL GAS FIRED.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THE BOILER SHALL BE EQUIPPED WITH A CONTROL SYSTEM TO AUTOMATICALLY REGULATE COMBUSTION AIR AND FUEL AS THE BOILER LOAD VARIES. THIS AUTOMATIC CONTROL SYSTEM SHALL BE ADJUSTED AND TUNED AT LEAST ONCE EVERY SIX MONTHS ACCORDING TO THE MANUFACTURER'S SPECIFICATIONS TO MAINTAIN ITS ABILITY TO REPEAT THE SAME PERFORMANCE AT THE SAME FIRING RANGE. NOX,  $O_2$ , AND CO SHALL BE MEASURED AND RECORDED ALONG WITH THE TUNE-UP PROCEDURES. [Rule 1146]
- 4. THE NO<sub>X</sub> AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

### POLLUTANTS PPMV

NO<sub>X</sub> 12 CO 100

[Rule 1303(a)-BACT]

5. THE OPERATOR SHALL NOT OPERATE ALL OF THE THREE BOILERS AT THE SAME TIME. [Rule 1303(b)(2)-OFFSET]

### **Periodic Monitoring:**

Section D Page 14
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G21364 A/N 487410

### **Equipment Description:**

BOILER NO. 3, WATERTUBE TYPE, CLEAVER BROOKS MODEL FLX 700-800, EQUIPPED WITH LOW NO  $_{\rm X}$  BURNER, 8 MMBTU/HR, NATURAL GAS FIRED.

#### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THE BOILER SHALL BE EQUIPPED WITH A CONTROL SYSTEM TO AUTOMATICALLY REGULATE COMBUSTION AIR AND FUEL AS THE BOILER LOAD VARIES. THIS AUTOMATIC CONTROL SYSTEM SHALL BE ADJUSTED AND TUNED AT LEAST ONCE EVERY SIX MONTHS ACCORDING TO THE MANUFACTURER'S SPECIFICATIONS TO MAINTAIN ITS ABILITY TO REPEAT THE SAME PERFORMANCE AT THE SAME FIRING RANGE. NOX, O<sub>2</sub>, AND CO SHALL BE MEASURED AND RECORDED ALONG WITH THE TUNE-UP PROCEDURES.
  [Rule 1146]
- 4. THE NO<sub>X</sub> AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

### POLLUTANTS PPMV

 $\begin{array}{cc} NO_X & 12 \\ CO & 100 \\ \text{[Rule 1303(a)-BACT]} \end{array}$ 

5. THE OPERATOR SHALL NOT OPERATE ALL OF THE THREE BOILERS AT THE SAME TIME. [Rule 1303(b)(2)-OFFSET]

### **Periodic Monitoring:**

Section D Page 15 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F99218 A/N 487445

### **Equipment Description:**

BOILER, WATERTUBE TYPE, PARKER BOILERS, MODEL T-3900LR, EQUIPPED WITH LOW NO $_{\rm X}$  BURNER, 3.9 MMBTU/HR, NATURAL GAS FIRED, AND A 3 H.P. COMBUSTION BLOWER.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THIS EQUIPMENT MAY NOT BURN MORE THAN 2,675,000 CUBIC FEET OF NATURAL GAS IN ANY ONE MONTH. A NON-RESETTABLE, TOTALIZING FUEL FLOW METER SHALL BE MAINTAINED IN THE FULE SUPPLY TO MEASURE THE AMOUNT OF NATURAL GAS BURNED. [RULE 1303(b)(2)-OFFSET]
- 4. THE  $NO_X$  AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

### POLLUTANTS PPMV

NO<sub>X</sub> 12 CO 100 [Rule 1303(a)-BACT]

### **Periodic Monitoring:**

Section D Page 16 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F99219 A/N 487446

### **Equipment Description:**

BOILER, WATERTUBE TYPE, PARKER BOILERS, MODEL T-3900LR, EQUIPPED WITH LOW NO $_{\rm X}$  BURNER, 3.9 MMBTU/HR, NATURAL GAS FIRED, AND A 3 H.P. COMBUSTION BLOWER.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THIS EQUIPMENT MAY NOT BURN MORE THAN 2,675,000 CUBIC FEET OF NATURAL GAS IN ANY ONE MONTH. A NON-RESETTABLE, TOTALIZING FUEL FLOW METER SHALL BE MAINTAINED IN THE FULE SUPPLY TO MEASURE THE AMOUNT OF NATURAL GAS BURNED. [RULE 1303(b)(2)-OFFSET]
- 4. THE  $NO_X$  AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

### POLLUTANTS PPMV

NO<sub>X</sub> 12 CO 100 [Rule 1303(a)-BACT]

### **Periodic Monitoring:**

Section D Page 17 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F99220 A/N 487447

### **Equipment Description:**

BOILER, WATERTUBE TYPE, PARKER BOILERS, MODEL T-3900LR, EQUIPPED WITH LOW  $NO_X$  BURNER, 3.9 MMBTU/HR, NATURAL GAS FIRED, AND A 3 H.P. COMBUSTION BLOWER.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THIS EQUIPMENT MAY NOT BURN MORE THAN 2,675,000 CUBIC FEET OF NATURAL GAS IN ANY ONE MONTH. A NON-RESETTABLE, TOTALIZING FUEL FLOW METER SHALL BE MAINTAINED IN THE FULE SUPPLY TO MEASURE THE AMOUNT OF NATURAL GAS BURNED. [RULE 1303(b)(2)-OFFSET]
- 4. THE NO<sub>X</sub> AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

### POLLUTANTS PPMV

NO<sub>X</sub> 12 CO 100 [Rule 1303(a)-BACT]

### **Periodic Monitoring:**

Section D Page 18 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. F99221 A/N 487448

### **Equipment Description:**

BOILER, WATERTUBE TYPE, PARKER BOILERS, MODEL T-3900LR, EQUIPPED WITH LOW NO $_{\rm X}$  BURNER, 3.9 MMBTU/HR, NATURAL GAS FIRED, AND A 3 H.P. COMBUSTION BLOWER.

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THIS EQUIPMENT MAY NOT BURN MORE THAN 2,675,000 CUBIC FEET OF NATURAL GAS IN ANY ONE MONTH. A NON-RESETTABLE, TOTALIZING FUEL FLOW METER SHALL BE MAINTAINED IN THE FULE SUPPLY TO MEASURE THE AMOUNT OF NATURAL GAS BURNED. [RULE 1303(b)(2)-OFFSET]
- 4. THE  $NO_X$  AND CO CONCENTRATIONS, IN PARTS PER MILLION BY VOLUME (PPMV), ON A DRY BASIS CORRECTED TO 3% OXYGEN, SHALL NOT EXCEED THE FOLLOWING:

### POLLUTANTS PPMV

 $\begin{array}{cc} NO_X & 12 \\ CO & 100 \\ \text{[Rule 1303(a)-BACT]} \end{array}$ 

### **Periodic Monitoring:**

Section D Page 19 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO CONSTRUCT/OPERATE

Permit No. G5761 A/N 497147

### **Equipment Description**

AIR POLLUTION CONTROL SYSTEM NO. 1 CONSISTING OF:

- 1. SCRUBBER, HARRINGTON, MODEL ECH 4, 4'-0" W. X 12'-0" L. X 7'-3". H, WITH SPRAY NOZZLE.
- 2. EXHAUST SYSTEM WITH TWO 20-HP BLOWERS. VENTING BENCH-TYPE POLISHING STATIONS.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.

  [RULE 204]
- 3. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF MARCH 7, 2008 OR EARLIER, EXCEPT FOR SODIUM HYDROXIDE (CAS # 1310-73-2), PHOSPHORIC ACID (CAS # 7664-38-20), AND HYDROCHLORIC ACID (CAS # 7647-01-0). [Rule 1401]
- 4. NOT LESS THAN 55 GALLONS PER MINUTE OF RECIRCULATING SCRUBBER SOLUTION SHALL BE SUPPLIED TO THE SCRUBBER SPRAY NOZZLES WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.
  [RULE 1303(a)(1)-BACT]
- 5. A FLOW METER INDICATING GALLONS PER MINUTE (GPM) SHALL BE MAINTAINED IN THE SCRUBBING SOLUTION CIRCULATION LINE TO THE SCRUBBER.

  [RULE 1303(a)(1)-BACT]
- 6. THE SCRUBBING SOLUTION TO THE SCRUBBER NOZZLES SHALL BE MAINTAINED AT pH 8.0 OR HIGHER. THE pH METER SHALL BE USED TO MEASURE THE pH OF THE SOLUTION ON A DAILY BASIS.

  [RULE 1303(a)(1)-BACT]

Section D Page 20 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### **Periodic Monitoring:**

Section D Page 21 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G13002 A/N 518884

### **Equipment Description**

AIR POLLUTION CONTROL SYSTEM CONSISTING OF:

- 1. SCRUBBER, HARRINGTON, MODEL ECH 44-5, 5'-8" W. x 11'-8" L x 6'-8" H, WITH SPRAY NOZZLE.
- 2. EXHAUST SYSTEM WITH TWO 20-HP BLOWERS, VENTING UP TO 10 ACID POLISHING BAYS.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER, EXCEPT FOR SODIUM HYDROXIDE, PHOSPHORIC ACID, HYDROCHLORIC ACID, SULFURIC ACID, NITRIC ACID, AND ETHYLENE GLYCOLS. [Rule 1401]
- 4. A DIFFERENTIAL PRESSURE GAUGE, INDICATING INCHES OF WATER COLUMN, SHALL BE INSTALLED AND MAINTAINED ACROSS THE SCRUBBER. THE DIFFERENTIAL PRESSURE ACROSS THE PACKING SHALL NOT EXCEED 2.0 INCHES OF WATER COLUMN WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]
- 5. A CONTINUOUS FLOW METER INDICATING THE FLOW RATE IN GALLONS PER MINUTE SHALL BE INSTALLED AND MAINTAINED ON THE RECIRCULATION LINE TO THE SCRUBBER. NOT LESS THAN 80 GALLONS PER MINUTE OF RECIRCULATING SCRUBBER SOLUTION SHALL BE SUPPLIED TO THE SCRUBBER SPRAY NOZZLES WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]
- 6. AN AUTOMATIC PH METER AND CONTROLLER SHALL BE INSTALLED AND MAINTAINED TO CONTINUOUSLY MEASURE AND RECORD THE pH OF THE RECIRCULATION SCRUBBING SOLUTION. THE SCRUBBING SOLUTION SHALL BE MAINTAINED AT pH 8.0 OR HIGHER WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]

Section D Page 22 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### **Periodic Monitoring:**

7. A DAILY OPERATION RECORD OF THIS EQUIPMENT SHALL BE MAINTAINED IN A WRITTEN FORM. THE RECORD SHALL INCLUDE, AT A MINIMUM, MINIMUM PH OF THE SCRUBBING SOLUTION, DIFFERENTIAL PRESSURE ACROSS THE SCRUBBER, AND FLOW RATE OF THE SCRUBBING SOLUTION AND MAKE UP WATER. THESE RECORDS SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND MADE AVAILABLE UPON REQUEST BY DISTRICT PERSONNEL. [RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 23 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G13004 A/N 518885

### **Equipment Description**

AIR POLLUTION CONTROL SYSTEM CONSISTING OF:

- 1. SCRUBBER, HARRINGTON, MODEL ECH 4, 4' -0" W. x 12' -0" L x 7' -3" H, WITH LANPAC POLYPROPYLENE PACKING MEDIA, SPRAY NOZZLES, AND MIST ELIMINATOR.
- 2. EXHAUST SYSTEM WITH TWO 5.36-HP BLOWERS, VENTING UP TO EIGHT ACID POLISHING BAYS.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER, EXCEPT FOR SODIUM HYDROXIDE, PHOSPHORIC ACID, HYDROCHLORIC ACID, SULFURIC ACID, NITRIC ACID, AND ETHYLENE GLYCOLS. [Rule 1401]
- 4. A DIFFERENTIAL PRESSURE GAUGE, INDICATING INCHES OF WATER COLUMN, SHALL BE INSTALLED AND MAINTAINED ACROSS THE SCRUBBER. THE DIFFERENTIAL PRESSURE ACROSS THE PACKING SHALL NOT EXCEED 2.0 INCHES OF WATER COLUMN WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]
- 5. A CONTINUOUS FLOW METER INDICATING THE FLOW RATE IN GALLONS PER MINUTE SHALL BE INSTALLED AND MAINTAINED ON THE RECIRCULATION LINE TO THE SCRUBBER. NOT LESS THAN 80 GALLONS PER MINUTE OF RECIRCULATING SCRUBBER SOLUTION SHALL BE SUPPLIED TO THE SCRUBBER SPRAY NOZZLES WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]

Section D Page 24
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

6. AN AUTOMATIC PH METER AND CONTROLLER SHALL BE INSTALLED AND MAINTAINED TO CONTINUOUSLY MEASURE AND RECORD THE pH OF THE RECIRCULATION SCRUBBING SOLUTION. THE SCRUBBING SOLUTION SHALL BE MAINTAINED AT pH 8.0 OR HIGHER WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

[RULE 1405]

### **Periodic Monitoring:**

7. A DAILY OPERATION RECORD OF THIS EQUIPMENT SHALL BE MAINTAINED IN A WRITTEN FORM. THE RECORD SHALL INCLUDE, AT A MINIMUM, MINIMUM PH OF THE SCRUBBING SOLUTION, DIFFERENTIAL PRESSURE ACROSS THE SCRUBBER, AND FLOW RATE OF THE SCRUBBING SOLUTION AND MAKE UP WATER. THESE RECORDS SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND MADE AVAILABLE UPON REQUEST BY DISTRICT PERSONNEL. [RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 25 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G13003 A/N 518886

### **Equipment Description**

AIR POLLUTION CONTROL SYSTEM CONSISTING OF:

- 1. SCRUBBER, HARRINGTON, MODEL ECH 4, 4' -0" W. x 12' -0" L x 7' -3" H, WITH LANPAC POLYPROPYLENE PACKING MEDIA, SPRAY NOZZLES, AND MIST ELIMINATOR.
- 2. EXHAUST SYSTEM WITH TWO 5.36-HP BLOWERS, VENTING UP TO EIGHT BENCH TYPE ACID POLISHING BAYS.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER, EXCEPT FOR SODIUM HYDROXIDE, PHOSPHORIC ACID, HYDROCHLORIC ACID, SULFURIC ACID, NITRIC ACID, AND ETHYLENE GLYCOLS. [Rule 1401]
- 4. A DIFFERENTIAL PRESSURE GAUGE, INDICATING INCHES OF WATER COLUMN, SHALL BE INSTALLED AND MAINTAINED ACROSS THE SCRUBBER. THE DIFFERENTIAL PRESSURE ACROSS THE PACKING SHALL NOT EXCEED 2.0 INCHES OF WATER COLUMN WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]
- 5. A CONTINUOUS FLOW METER INDICATING THE FLOW RATE IN GALLONS PER MINUTE SHALL BE INSTALLED AND MAINTAINED ON THE RECIRCULATION LINE TO THE SCRUBBER. NOT LESS THAN 80 GALLONS PER MINUTE OF RECIRCULATING SCRUBBER SOLUTION SHALL BE SUPPLIED TO THE SCRUBBER SPRAY NOZZLES WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.

  [RULE 1405]

Section D Page 26 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

6. AN AUTOMATIC PH METER AND CONTROLLER SHALL BE INSTALLED AND MAINTAINED TO CONTINUOUSLY MEASURE AND RECORD THE pH OF THE RECIRCULATION SCRUBBING SOLUTION. THE SCRUBBING SOLUTION SHALL BE MAINTAINED AT pH 8.0 OR HIGHER WHEN THE EQUIPMENT IT SERVES IS IN OPERATION.
[RULE 1405]

### **Periodic Monitoring:**

7. A DAILY OPERATION RECORD OF THIS EQUIPMENT SHALL BE MAINTAINED IN A WRITTEN FORM. THE RECORD SHALL INCLUDE, AT A MINIMUM, THE MINIMUM PH OF THE SCRUBBING SOLUTION, DIFFERENTIAL PRESSURE ACROSS THE SCRUBBER, AND FLOW RATE OF THE SCRUBBING SOLUTION AND MAKE UP WATER. THESE RECORDS SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND MADE AVAILABLE UPON REQUEST BY DISTRICT PERSONNEL. [RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 27 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G15506 A/N 524958

### **Equipment Description**

#### PLASTIC EXTRUSION LINE #1 CONSISTING OF:

- 1. HOPPER, WITH A DRYER, EDD NO. 2067198, 1.66 W ELECTRICALLY HEATED, DRI-AIR, ARID-X10, 1'D X 2'6"H
- 2. EXTRUDER, 70 RPM, EDD NO. 2068465, WITH A 2.25 KW ELECTRICALLY HEATED BARREL MELTER, AND A 3 HP MIXER, 4"W X 1'10"L X 4"H

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER.
  [RULE 1401]
- 4. THIS EQUIPMENT SHALL NOT PROCESS MORE THAN 7200 POUNDS OF MATERIAL PER MONTH. [RULE 1303(b)(2)-OFFSET]

### **Periodic Monitoring:**

5. A MONTHLY OPERATION RECORD OF THIS EQUIPMENT SHALL BE MAINTAINED IN A WRITTEN FORM. THESE RECORDS SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND MADE AVAILABLE UPON REQUEST BY DISTRICT PERSONNEL.

[RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 28 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G15507 A/N 526846

### **Equipment Description**

PLASTIC EXTRUSION LINE #8 CONSISTING OF:

- 1. HOPPER (SHARED), WITH A DRYER, EDD NO. 2067198, 1.66 W ELECTRICALLY HEATED, DRI-AIR, ARID-X10, 1'D X 2'6"H
- 2. EXTRUDER, 35 RPM, EDD NO. 2068464, WITH A 2.25 KW ELECTRICALLY HEATED BARREL MELTER, AND A 3 HP MIXER, 4.75"W X 1'10"L X 4.75"H

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER.
  [RULE 1401]
- 4. THIS EQUIPMENT SHALL NOT PROCESS MORE THAN 7200 POUNDS OF MATERIAL PER MONTH. [RULE 1303(b)(2)-OFFSET]

### **Periodic Monitoring:**

5. A MONTHLY OPERATION RECORD OF THIS EQUIPMENT SHALL BE MAINTAINED IN A WRITTEN FORM. THESE RECORDS SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND MADE AVAILABLE UPON REQUEST BY DISTRICT PERSONNEL.
[RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 29 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO OPERATE

Permit No. G16455 A/N 529249

### **Equipment Description**

LASER CUTTING AND LATHING SYSTEM, BUILDING A, CONSISTING OF:

- 1. 11 LASERS, SPI FIBER, EACH 100 WATTS MAXIMUM, 5 10 WATTS IN USE
- 2. 5 LASERS, LASAQ, EACH 250 WATTS MAXIMUM, 5 10 WATTS IN USE

### **Conditions:**

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THIS EQUIPMENT SHALL NOT PROCESS MORE THAN 6400 STENTS IN ANY ONE DAY. [RULE 1401]
- 4. THIS EQUIPMENT SHALL NOT PROCESS MORE THAN 1280 STAINLESS STEEL STENTS IN ANY ONE DAY.

  [RULE 1401]
- 5. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER, EXCEPT FOR CHROMIUM (NOT TO EXCEED 21%), OR NICKEL (NOT TO EXCEED 15%).

  [Rule 1401]

### **Periodic Monitoring**

6. THE OPERATOR SHALL KEEP A DAILY RECORD OF THE NUMBER OF STENTS AND THE TYPE OF ALLOY PROCESSED. SUCH RECORD SHALL BE KEPT FOR A MINIMUM OF FIVE YEARS AND SHALL BE AVAILABLE TO DISTRICT STAFF UPON REQUEST.

[RULE 3004(a)(4) MONITORING AND RECORDKEEPING]

Section D Page 30 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO CONSTRUCT

Permit No. GXXXX A/N 560736

### **Equipment Description**

SPRAY BOOTH, COAST INDUSTRIAL SYSTEMS, FLOOR TYPE,  $10^{\circ}-4^{\circ}$  W.  $\times$   $19^{\circ}-2^{\circ}$ D.  $\times$   $14^{\circ}-4^{\circ}$  H., WITH FOURSTAGE FILTER SYSTEM CONSISTING OF THIRTY  $20^{\circ}\times20^{\circ}\times1^{\circ}$  PRE-FILTERS, THIRTY  $20^{\circ}\times20^{\circ}\times2^{\circ}$  PANEL FILTERS, THIRTY  $20^{\circ}\times20^{\circ}\times15^{\circ}$  BAG POCKET FILTERS, SIXTEEN  $24^{\circ}\times24^{\circ}\times12^{\circ}$  HEPA FILTERS AND ONE 15-HP EXHAUST FAN.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT WAS ISSUED, UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THIS SPRAY BOOTH SHALL NOT BE OPERATED UNLESS ALL EXHAUST AIR PASSES THROUGH THE PRE-FILTERS, BAG-TYPE FILTERS AND HEPA FILTERS.

  [RULE 1303(A)(1) BACT]
- 4. THE OPERATIONS CONDUCTED IN THIS SPRAY BOOTH SHALL COMPLY WITH RULE 1107 AND 1469.1.
  [RULE 1107, RULE 1469.1]
- 5. THE OPERATOR SHALL INSTALL THE HEPA FILTERS RATED AT 99.97% OR MORE EFFICIENT IN COLLECTING PARTICLE SIZES 0.3 MICRONS OR GREATER IN SIZE.

  [RULE 1303(A)(1) BACT, RULE 1469.1]
- 6. THE OPERATOR SHALL NOT TURN OFF THE EXHAUST FAN OF THIS EQUIPMENT UNTIL 5
  MINUTES AFTER SPRAYING OPERATIONS HAVE CEASED WHEN COATINGS CONTAINING
  HEXAVALENT CHROME HAVE BEEN SPRAYED. THE OPERATOR SHALL MAINTAIN RECORDS
  IN A MANNER APPROVED BY THE DISTRICT, TO DEMONSTRATE COMPLIANCE WITH THIS
  CONDITION.
  [RULE 1469.1]
- 7. THE OPERATOR SHALL INSTALL AND MAINTAIN A MECHANICAL GAUGE TO INDICATE, IN INCHES WATER COLUMN, THE STATIC PRESSURE DIFFERENTIAL ACROSS THE HEPA FILTERS. [RULE 1303(A)(1) BACT]
- 8. THE PRESSURE DROP ACROSS THE HEPA FILTERS SHALL NOT EXCEED 5 INCHES WATER COLUMN.

Section D Page 31 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

[RULE 1303(A)(1) - BACT]

- 9. THE OPERATOR SHALL LIMIT THE AMOUNT OF COATING MATERIALS USED IN THIS EQUIPMENT TO NO MORE THAN 440 POUNDS PER MONTH.

  [RULE 1303(B)(2) OFFSET]
- 10. MATERIALS USED IN THIS EQUIPMENT SHALL NOT CONTAIN ANY TOXIC AIR CONTAMINANTS IDENTIFIED IN RULE 1401, TABLE I, WITH AN EFFECTIVE DATE OF SEPTEMBER 10, 2010 OR EARLIER, EXCEPT FOR THE FOLLOWING AT THE ANNUAL USAGE LIMITS AS SHOWN BELOW:

TOXIC AIR CONTAMINANT CAS NO. ANNUAL USAGE (LBS/YR)
CHROMIC ACID 1333-82-0 396
PHOSPHORIC ACID 7664-38-2 316.8

[RULE 1401]

- 11. THE OWNER OR OPERATOR OF THIS EQUIPMENT SHALL CONDUCT SOURCE TEST(S) UNDER THE FOLLOWING CONDITIONS:
  - A. THE SOURCE TEST(S) SHALL BE CONDUCTED NO LATER THAN 180 DAYS AFTER THE INITIAL START-UP OF THIS EQUIPMENT UNLESS OTHERWISE APPROVED IN WRITING BY THE DISTRICT.
  - B. THE SOURCE TEST(S) SHALL BE PERFORMED TO MEASURE HEXAVALENT AND TOTAL CHROME EMISSION LEVELS.
  - C. DURING THE SOURCE TEST, THE FOLLOWING OPERATING PARAMETERS AND MATERIAL USAGES, BUT NOT BE LIMITED TO, SHALL BE RECORDED:
    - (1) TOTAL AND HEXAVALENT CHROME EMISSIONS AT THE EXHAUST, IN LBS/HR,
    - (2) DIFFERENTIAL PRESSURES ACROSS HEPA FILTERS, IN INCHES OF WATER,
    - (3) USAGE OF THE COATING MATERIAL(S), IN GALLONS AND POUNDS,
    - (4) AMOUNT OF ACID ACCELERATOR (CHROMIC AND PHOSPHORIC ACID) ADDED TO THE COATING MIXTURE, IN WT%,
    - (5) EXHAUST FLOW RATE, AND
    - (6) TEMPERATURE.
  - D. THE TESTS SHALL BE CONDUCTED WHILE THE SPRAY GUN IS OPERATING AT MAXIMUM SPRAYING RATES.
  - E. THE TEST SHALL BE CONDUCTED USING CARB METHOD 425.
  - F. TWO COMPLETE COPIES OF THE SOURCE TEST REPORTS SHALL BE SUBMITTED TO THE DISTRICT (ADDRESSED TO SOUTH COAST AIR QUALITY MANAGEMENT DISTRICT, ATTN: STEPHEN JIANG, P.O. BOX 4941, DIAMOND BAR, CA 91765) WITHIN 45 DAYS AFTER THE SOURCE TEST DATE.

Section D Page 32 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

- G. A TESTING LABORATORY CERTIFIED BY THE CALIFORNIA AIR RESOURCES BOARD AND/OR THE SCAQMD LABORATORY APPROVAL PROGRAM, AND IN COMPLIANCE WITH DISTRICT RULE 304 (NO CONFLICT OF INTEREST) SHALL CONDUCT THE TEST.
- H. SAMPLING FACILITIES SHALL COMPLY WITH THE DISTRICT GUIDELINES FOR CONSTRUCTION OF SAMPLING AND TESTING FACILITIES, PURSUANT TO RULE 217.

[RULE 1401; RULE 212]

### **Periodic Monitoring**

- 12. MATERIAL SAFETY DATA SHEETS FOR ALL MATERIALS USED IN THIS EQUIPMENT SHALL BE KEPT CURRENT AND BE MADE AVAILABLE TO THE EXECUTIVE OFFICER OR HIS REPRESENTATIVE UPON REQUEST.

  [RULE 3004 (A)(4)]
- 13. THE OPERATOR SHALL MAINTAIN ADEQUATE RECORDS TO VERIFY COMPLIANCE WITH CONDITION NOS. 4, 6, 7, 8 AND 9 ABOVE. SUCH RECORDS SHALL BE KEPT ON THE PREMISES FOR AT LEAST FIVE YEARS AND BE MADE AVAILABLE TO THE EXECUTIVE OFFICER OR HIS REPRESENTATIVE UPON REQUEST.

  [RULE 3004 (A)(4)]

### **Emissions and Requirements:**

14. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

VOC: RULE 1107 Cr<sup>6+</sup>: RULE 1469.1

Section D Page 33 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### PERMIT TO CONSTRUCT

A/N 572699 Granted as of XX/XX/XXXX

### **Equipment Description**

#### STERILIZATION SYSTEM CONSISTING OF:

- 1. STERILIZER, NOXILIZER, MODEL RTS 360, 6'-6" L. X 6'-6" W. X 6'-6" H.
- 2. NO<sub>2</sub> CYLINDERS, 2 POUND CAPACITY.
- 3. INTEGRATED TWO STAGE SCRUBBER SYSTEM CONSISTING OF:
  - A. THREE PRIMARY SCRUBBERS IN PARALLEL, EACH WITH 3.6 KG OF PURAFIL SP CHEMISORBANT MEDIA CONTAINING SODIUM PERMANGANATE.
  - B. ONE SECONDARY SCRUBBER WITH TWO SECTION IN SERIES, EACH WITH 1 KG OF PURAFIL SP CHEMISORBENT MEDIA CONTAINING SODIUM PERMANGANATE.
  - C. 1.6 HP EXHAUST FAN.

- 1. OPERATION OF THIS EQUIPMENT SHALL BE CONDUCTED IN ACCORDANCE WITH ALL DATA AND SPECIFICATIONS SUBMITTED WITH THE APPLICATION UNDER WHICH THIS PERMIT IS ISSUED UNLESS OTHERWISE NOTED BELOW.

  [RULE 204]
- 2. THIS EQUIPMENT SHALL BE PROPERLY MAINTAINED AND KEPT IN GOOD OPERATING CONDITION AT ALL TIMES.
  [RULE 204]
- 3. THE OPERATOR SHALL NOT OPERATE THIS STERILIZER UNLESS IT IS VENTED TO THE INTEGRATED TWO-STAGE SCRUBBER SYSTEM.
  [RULE 1303(A)(1)-BACT]
- 4. THE MAXIMUM NO2 DISPENSED PER PULSE BY THIS EQUIPMENT SHALL NOT EXCEED 20 MILLIGRAMS OF NO2 PER LITER.
  [RULE 1303(B)(2)-OFFSETS]
- 5. THERE SHALL BE NO MORE THAN 480 PULSES OF  $NO_2$  DISPENSED IN ANY ONE CALENDAR MONTH. [RULE 1303(B)(2)-OFFSETS]
- 6. AN ELECTROCHEMICAL SENSOR SHALL BE INSTALLED BETWEEN THE TWO SECTIONS OF THE SECONDARY SCRUBBER. THE SENSOR SHALL BE PROGRAMMED TO TRIGGER AN ALARM IF THE NO<sub>2</sub> CONCENTRATION EXCEEDS 1 PPM.

Section D Page 34
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

[RULE 1303(A)(1)-BACT]

- 7. THE ELECTROCHEMICAL SENSOR SHALL BE CALIBRATED TO TRIGGER AN ALARM IS THE NO2 CONCENTRATION EXCEEDS 1 PPM.
  [RULE 1303(B)(2)-OFFSETS]
- 8. THE NO2 CONCENTRATION IN THE SECONDARY SCRUBBER EXHAUST SHALL NOT EXCEED 1 PPM NO<sub>2</sub>. THE CONCENTRATION SHALL BE RECORDED AT LEAST ONCE PER DAY. [RULE 1303(B)(2)-OFFSETS]
- 9. THE CHEMISORBENT MEDIA IN THE PRIMARY AND SECONDARY SCRUBBERS SHALL BE REPLACED WITH FRESH MEDIA EACH TIME AN NO $_2$  CYLINDER IS REPLACED. [RULE 1303(A)(1)-BACT]

### **Periodic Monitoring**

10. RECORDS SHALL BE KEPT TO VERIFY THE MAXIMUM  $\mathrm{NO_2}$  DISPENSED PER PULSE IN  $\mathrm{mg}$  OF  $\mathrm{NO_2}$  PER LITER, THE NUMBER OF PULSES OF  $\mathrm{NO_2}$  DISPENSED PER CALENDAR MONTH, THE  $\mathrm{NO_2}$  CONCENTRATION IN THE SECONDARY SCRUBBER EXHAUST, AND THE DATE OF EACH REPLACEMENT OF AN  $\mathrm{NO_2}$  CYLINDER. ALL RECORDS SHALL BE KEPT IN A FORMAT ACCEPTABLE TO THE DISTRICT, SHALL BE RETAINED AT THE FACILITY FOR AT LEAST 2 YEARS, AND SHALL BE MADE AVAILABLE TO ANY DISTRICT PERSONNEL UPON REQUEST. [RULE 3004(A)(4)MONITORING AND RECORDKEEPING]

Section D Page 35 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### **RULE 219 EQUIPMENT**

### **Equipment Description:**

RULE 219 EXEMPT EQUIPMENT, COATING EQUIPMENT, PORTABLE, ARCHITECTURAL COATINGS.

### **Periodic Monitoring:**

1. THE OPERATOR SHALL KEEP RECORDS, IN A MANNER APPROVED BY THE DISTRICT, FOR THE FOLLOWING PARAMETER(S) OR ITEM(S):

FOR ARCHITECTURAL APPLICATIONS WHERE NO THINNERS, REDUCERS, OR OTHER VOC CONATINING MATERIALS ARE ADDED, MAINTAIN SEMI-ANNUAL RECORDS OF ALL COATINGS CONSISITING OF (a) COATING TYPE, (b) VOC CONTENT AS SUPPLIED IN GRAMS PER LITER (g/l) OF MATERIALS FOR LOW-SOLIDS COATINGS, (c) VOC CONTENT AS SUPPLIED IN g/l OF COATING, LESS WATER AND EXEMPT SOLVENT, FOR OTHER COATING.

FOR OTHER ARCHITECTURAL APPLICATIONS WHERE THINNERS, REDUCERS, OR OTHER VOC CONATINING MATERIALS ARE ADDED, MAINTAIN DAILY RECORDS FOR EACH COATING CONSITING OF (a) COATING TYPE, (b) VOC CONTENT AS APPLIED IN GRAMS PER LITER (g/l) OF MATERIALS USED FOR LOW-SOLIDS COATINGS, (c) VOC CONTENT AS APPLIED IN g/l OF COATING, LESS WATER AND EXEMPT SOLVENT, FOR OTHER COATING.

[RULE 3004 (a) (4) MONITORING AND RECORDKEEPING]

### **Emissions And Requirements:**

2. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

VOC: RULE 1113, SEE APPENDIX B FOR EMISSION LIMITS VOC: RULE 1171, SEE APPENDIX B FOR EMISSION LIMITS

[RULE 1113, RULE 1171]

Section D Page 36
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

## **RULE 219 EQUIPMENT**

### **Equipment Description:**

RULE 219 EXEMPT EQUIPMENT, HAND WIPING OPERATIONS.

### **Emissions And Requirements:**

1. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

VOC: RULE 1171, SEE APPENDIX B FOR EMISSION LIMITS

[RULE 1171]

Section D Page 37 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

## **RULE 219 EQUIPMENT**

### **Equipment Description:**

RULE 219 EXEMPT EQUIPMENT, BOILER, > 400,000 BTU/HR BUT < 2 MMBTU/HR.

### **Emissions And Requirements:**

1. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

PM: 0.1 gr/scf, RULE 409 NOx: 30 PPMV, RULE 1146.2 CO: 400 PPMV, RULE 1146.2 CO: 2000 PPMV, RULE 407

Section D Page 38 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### **RULE 219 EQUIPMENT**

### **Equipment Description:**

RULE 219 EXEMPT EQUIPMENT, ABRASIVE BLASTING EQUIPMENT, GLOVE-BOX, < 53 FT3, WITH DUST FILTER.

### **Periodic Monitoring:**

- 1. THE OPERATOR SHALL PERFORM AN ANNUAL INSPECTION OF THE EQUIPMENT AND FILTER MEDIA FOR LEAKS, BROKEN OR TORN FILTER MEDIA AND IMPROPERLY INSTALLED FILTER MEDIA. THE OPERATOR SHALL KEEP RECORDS, IN A MANNER APPROVED BY THE DISTRICT, FOR THE FOLLOWING PARAMETER(S) OR ITEM(S):
  - A. THE NAME OF THE PERSON PERFORMING THE INSPECTION AND/OR MAINTENANCE OF THE FILTER MEDIA;
  - B. THE DATE, TIME AND RESULTS OF THE INSPECTION; AND
  - C. THE DATE, TIME AND DESCRIPTION OF ANY MAINTENANCE OR REPAIRS RESULTING FROM THE INSPECTION.

[RULE 3004 (a)(4) MONITORING AND RECORDKEEPING]

2. THE OPERATOR SHALL DISCHARGE DUST COLLECTED IN THIS EQUIPMENT ONLY INTO CLOSED CONTAINERS.

[RULE 3004 (a)(1)]

3. THE OPERATOR SHALL CONDUCT AN INSPECTION FOR VISIBLE EMISSIONS FROM ALL STACKS AND OTHER EMISSION POINTS OF THIS EQUIPMENT WHENEVER THERE IS A PUBLIC COMPLAINT OF VISIBLE EMISSIONS, WHENEVER VISIBLE EMISSIONS ARE OBSERVED, AND ON AN ANNUAL BASIS, AT LEAST, UNLESS THE EQUIPMENT DID NOT OPERATE DURING THE ENTIRE ANNUAL PERIOD. THE ROUTINE ANNUAL INSPECTION SHALL BE CONDUCTED WHILE THE EQUIPMENT IS IN OPERATION AND DURING DAYLIGHT HOURS. IF ANY VISIBLE EMISSIONS (NOT INCLUDING CONDENSED WATER VAPOR) ARE DETECTED, THE OPERATOR SHALL TAKE CORRECTIVE ACTION(S) THAT ELIMINATES THE VISIBLE EMISSIONS WITHIN 24 HOURS AND REPORT THE VISIBLE EMISSIONS AS A POTENTIAL DEVIATION IN ACCORDANCE WITH THE REPORTING REQUIREMENTS IN SECTION K OF THIS PERMIT.

THE OPERATOR SHALL KEEP THE RECORDS IN ACCORDANCE WITH THE RECORDKEEPING REQUIREMENTS IN SECTION K OF THIS PERMIT AND THE FOLLOWING RECORDS:

- A. STACK OR EMISSION POINT IDENTIFICATION:
- B. DESCRIPTION OF ANY CORRECTIVE ACTIONS TAKEN TO ABATE VISIBLE EMISSIONS; AND
- C. DATE AND TIME VISIBLE EMISSION WAS ABATED. [RULE 3004 (a)(4) MONITORING AND RECORDKEEPING]

Section D Page 39
Facility I.D.#: 045489
Revision #: DRAFT
Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

### **Emissions And Requirements:**

4. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

PM: RULE 404, SEE APPENDIX B FOR EMISSION LIMITS
 PM: RULE 405, SEE APPENDIX B FOR EMISSION LIMITS
 PM: RULE 1140, SEE APPENDIX B FOR EMISSION LIMITS

Section D Page 40 Facility I.D.#: 045489 Revision #: DRAFT Date: April 30, 2015

# FACILITY PERMIT TO OPERATE ABBOTT CARDIOVASCULAR SYSTEMS, INC.

## **RULE 219 EQUIPMENT**

### **Equipment Description:**

RULE 219 EXEMPT EQUIPMENT, COATING EQUIPMENT, VOC EMISSIONS THREE POUNDS PER DAY OR LESS OR 66 POUNDS PER CALENDAR MONTH OR LESS.

### **Emissions And Requirements:**

1. THIS EQUIPMENT IS SUBJECT TO THE APPLICABLE REQUIREMENTS OF THE FOLLOWING RULES AND REGULATIONS:

VOC: RULE 1145, SEE APPENDIX B FOR EMISSION LIMITS VOC: RULE 1171, SEE APPENDIX B FOR EMISSION LIMITS

[RULE 1145, RULE 1171]